


FRONT FOG LIGHTS (OPTION)

< > WITH CRUISE CONTROL SYSTEM

Z-40



<p>E4-01 FRONT FOG LIGHT SWITCH(1)</p> <table border="1"> <tr> <td>*</td> <td>P/L</td> <td>R/B</td> </tr> <tr> <td>R/G</td> <td>R</td> <td>GY/R</td> </tr> </table> <p>(WITHOUT CRUISE CONTROL SYSTEM) (OPTION)</p>	*	P/L	R/B	R/G	R	GY/R	<p>E4-02 FRONT(F)-FRONT FOG LIGHTS(SHORT CORD) (F)</p> <p>(FRONT FOG LIGHTS)</p> <table border="1"> <tr> <td>R/Y</td> <td>P/L</td> <td>R/G</td> </tr> <tr> <td>C</td> <td>B</td> <td>A</td> </tr> </table> <p>(OPTION)</p> <table border="1"> <tr> <td>1</td> <td>2</td> <td>3</td> </tr> <tr> <td>A</td> <td>B</td> <td>C</td> </tr> </table> <p>TERMINALS OF THIS CONNECTOR ARE INDICATED BY NUMBERS.</p>	R/Y	P/L	R/G	C	B	A	1	2	3	A	B	C	<p>Q-02 FRONT FOG LIGHT SWITCH(1)</p> <table border="1"> <tr> <td>GY/R</td> <td>*</td> <td></td> <td>*</td> <td>R/B</td> </tr> <tr> <td>R/G</td> <td>P/L</td> <td>R</td> <td>B/Y</td> <td>R/Y</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>B</td> </tr> </table> <p>(WITH CRUISE CONTROL SYSTEM)</p>	GY/R	*		*	R/B	R/G	P/L	R	B/Y	R/Y					B
*	P/L	R/B																																	
R/G	R	GY/R																																	
R/Y	P/L	R/G																																	
C	B	A																																	
1	2	3																																	
A	B	C																																	
GY/R	*		*	R/B																															
R/G	P/L	R	B/Y	R/Y																															
				B																															