



CLUTCH/TRANSMISSION PARTS—Cont'd			ENGINE PARTS—Cont'd		
Item	Part Number	Remarks	Item	Part Number	Remarks
Release Collar	B622-16-510		Ring Gear	B367-11-502	
Master Cylinder	NA01-41-400A			0110-11-502	
Release Cylinder	NA01-41-920		Oil Filler Cap	0453-10-250A	
	<AN> <b>NA01-41-920B</b>		Intake Manifold Gasket	BP4W-13-111	
Release Cylinder Kit	H005-49-460		Exhaust Manifold Gasket	BPD3-13-460	
	<AN> <b>FB01-49-460</b>		Crankshaft Oil Seal	FS05-10-602A	
Clutch Pilot Bearing	F801-11-303	M/T	Camshaft Oil Seal	BP05-11-312	
			Oil Pan Gasket	B6F4-10-427	
				B6F4-10-428	
ELECTRICAL			FUEL & EXHAUST SYSTEMS		
Item	Part Number	Remarks	Item	Part Number	Remarks
Alternator	BP4W-18-300B		Pump, Fuel	BP4W-13-35ZE	NB353*137711-139968
	<A> <b>BP4W-18-300R-0C</b>			<C> <b>BP4W-13-35ZG</b>	
Starter	BPD4-18-400A		Cap, Filler	NC10-42-250	NB353*-124510
	<A> <b>BPD4-18-400R-00</b>			<AN> <b>NC10-42-250B</b>	
Oxygen Sensor	BP3B-18-861	Illust. No. 1 Fed.		NC10-42-250A	NB353*124510-138751
	<AN> <b>BP3B-18-86Z-9U</b>			<AN> <b>NC10-42-250B</b>	
	BP4X-18-861	Illust. No. 2		NC49-42-250	NB353*138751-
	<AN> <b>BP4X-18-861A-9U</b>			<A> <b>NC10-42-250B</b>	
	BP4Y-18-861C	Illust. No. 1	Front Pipe	BPM3-40-500C	NB353*-101122
	<AN> <b>BP4Y-18-861C-9U</b>			<AN> <b>BPM3-40-500F</b>	
Ignition Switch	N053-66-151			BPM3-40-500D	NB353*101122-
Oil Pressure Switch	B367-18-501			<AN> <b>BPM3-40-500F</b>	
Stoplight Switch	BR70-66-490A	w/ ACC		BP4Y-20-500C	Calif.
	B001-66-490A	w/o ACC		BPM1-40-100C	NB353*-119466
	<AN> <b>B001-66-490B</b>			<AN> <b>BPM1-40-100E</b>	
	UH71-66-490	w/o ACC		BPM1-40-100D	NB353*119466-
Water Temp Switch	KLK1-18-840			<AN> <b>BPM1-40-100E</b>	
				BPM3-40-100C	NB353*-122952
ENGINE PARTS				<AN> <b>BPM3-40-100G</b>	
Item	Part Number	Remarks		BPM3-40-100D	NB353*122952-
Engine Gasket Set	8AN3-10-271			<AN> <b>BPM3-40-100G</b>	
	<AN> <b>8DN3-10-271</b>		Gasket	BPM1-40-450A	Cnvtr.
Cylinder Head Gasket Set	8AN3-10-235		Exhaust Gasket	Z510-40-305	Illust. No. 1, A/T
	<AN> <b>8DN3-10-235</b>			<AN> <b>FSB8-40-305</b>	
Valve Cover Gasket	BP05-10-235C			Z520-40-305	Illust. No. 2, M/T
Valve Guide	B6Z1-10-280	Intake		BP47-40-061	NB353*-106606
	BPY0-10-290	Exhaust		<AN> <b>KL16-40-061</b>	
Valve Seal	KL01-10-155		Hanger	BP47-40-061A	NB353*106606-
	KL02-10-155				
Intake Valve	BP2Y-12-111	NB353*-122764	LIGHTING		
	BP4W-12-111	NB353*122764-	Item	Part Number	Remarks
Exhaust Valve	BP4W-12-121		Brake & Tail Bulb	9970-06-210	
Crank Pulley	BP4W-11-401		Turn Signal Bulb	9970-16-038	
	BPD4-11-401			<AN> <b>0000-11-0194</b>	
Timing Belt	B6S7-12-205D		Back-Up Light Bulb	9970-13-210	
	<AN> <b>B6S7-12-205D-9U</b>		License Plate Bulb	0000-11-0194	
Tensioner	B660-12-700E		Side Marker Bulb	0000-11-0194	
	<AN> <b>B660-12-700F</b>				
Flywheel	BPR7-11-500	M/T			
	<A> <b>BPR7-11-500A</b>				

LIGHTING—Cont'd		
Item	Part Number	Remarks
Combination Bulb	0000-11-0194	Front
High Mt. Brake Bulb	9970-07-180	
	<AN> <b>0000-11-0921</b>	
Dashboard Bulb	0000-11-0194	3.4 W
Headlamp Bulb	9970-32-605	
	<AN> <b>0000-11-9003</b>	
SHOCKS & STEERING		
Item	Part Number	Remarks
Front Shock	NC10-34-700C	w/o ABS
	NC12-34-700	w/ ABS
	<A> <b>NC12-34-700D</b>	
Rear Shock	NC10-28-700C	Normal
	NC12-28-700C	Hard, -130051
	<AN> <b>NC12-28-700D</b>	
	NC12-28-700D	Hard, 130051-
Bushing, Rubber, Lwr.	NA01-28-4B0	Right
	NA01-28-4D0	
WIPERS & WASHERS		
Item	Part Number	Remarks
Front Blade Insert	B16B-67-333	
Wiper Blade, Front	NC11-67-330	Right
	<AN> <b>NC11-67-330 -9U</b>	
	NC10-67-330	Left
	<AN> <b>NC10-67-330 -9U</b>	
Wiper Insert	D040-67-331A	
	<AN> <b>D040-67-333 -9U</b>	
Wiper Arm (R)	NC11-67-321	Passenger Side
Wiper Arm (L)	NC10-67-321	Driver Side
Washer Pump	S084-76-672	
Wiper Motor	NA01-67-340D	NB353*-100063
	<AN> <b>NA01-67-340E</b>	
	NA01-67-340E	NB353*100063-
	NA04-67-340D	
Nozzle, Washer	NC10-67-510	Illust. No. 1, w/ ABS
	NC11-67-510	Illust. No. 2
Cap, Tank	UB39-51-815	1.5L Washer Tank
	GJ21-67-483	Non USA
Tank, Washer	NA01-67-481	1.5L Washer Tank