

TunerStudio MS v2.0.8 - MS3 1 Registered to: publico morera

File Options Data Logging Communications Tools Help

Basic Load Settings Spark Advance Table1

Gauge Cluster Diagnostic 3D Tuning Maps CAN-bus/Testmodes

File 3D View

180.0	12.0	13.0	14.0	15.0	16.0	17.0	18.0	19.0	18.5	18.0	17.5	17.0	16.5	16.0	15.5	15.0
140.0	13.0	14.0	18.0	21.0	21.4	21.8	22.2	22.6	23.0	23.4	23.8	24.2	23.8	23.4	23.0	22.6
120.0	15.0	16.0	19.5	22.0	22.5	23.0	23.5	24.0	24.5	25.0	25.5	26.0	26.5	27.0	26.0	27.0
110.0	20.0	20.0	22.0	24.5	27.5	28.0	29.0	30.3	30.4	30.5	30.6	30.7	30.1	31.1	30.1	32.0
100.0	21.0	21.0	23.0	25.0	28.0	28.5	29.4	29.8	30.0	30.2	30.4	30.6	30.8	31.8	30.8	33.0
90.0	22.0	23.0	24.0	25.7	28.5	29.0	29.8	30.2	30.4	31.0	32.0	33.0	33.5	33.5	32.5	33.5
85.0	24.0	22.0	23.0	25.5	29.0	29.5	30.0	30.4	30.6	31.4	33.0	33.5	34.0	34.0	34.0	34.0
80.0	25.0	21.0	22.0	25.3	30.2	30.4	30.2	30.6	30.8	31.8	33.5	34.0	34.5	34.5	34.5	34.5
75.0	24.0	20.5	21.5	25.1	30.0	30.2	30.4	30.8	31.0	32.2	34.0	34.5	35.0	35.0	35.0	35.0
70.0	22.0	20.0	21.0	25.4	29.8	30.0	30.6	31.0	31.2	32.0	34.5	35.0	35.5	35.5	35.5	35.5
65.0	20.0	19.5	21.5	26.7	29.6	29.8	30.8	31.2	31.4	32.5	35.0	35.5	36.0	36.0	36.0	36.0
60.0	18.0	19.0	21.0	27.0	29.4	29.6	31.0	31.4	31.6	32.0	35.5	36.5	37.0	37.0	37.0	37.0
50.0	16.0	18.0	21.0	26.8	29.2	29.4	31.4	31.8	32.0	33.0	36.0	37.5	38.0	38.0	38.0	38.0
40.0	14.0	16.0	21.0	26.4	28.8	29.0	31.8	32.2	32.0	34.0	37.0	39.0	39.0	39.0	39.0	39.0
30.0	12.0	14.0	20.5	26.0	28.4	28.6	32.2	32.6	33.0	35.0	38.0	40.0	40.0	40.0	40.0	40.0
20.0	10.0	12.0	20.0	25.6	28.0	28.2	32.6	33.0	34.0	36.0	39.0	41.0	41.0	41.0	41.0	41.0
	800	1200	1400	1600	1800	2000	2200	2400	2600	2800	3200	3600	4000	4600	5200	7000
	rpm															

Burn Close

WT2 err	BATT fault	Knock fault	WUE OFF	Overboost	Config Error	Flex fault	Not Ready	SPK1/2	TPS Accel	No soft limit	CLT fault	T-log
AFR0 fault	Data Lost	Test mode	AFR shutdown	No 3 step	Check Engine	Limp mode	EGT fault	MAF fault	WV4 err	MAP Decel	Idle Adv	MAP Accel
VE1/2	MAT fault	WT1 err	Not Cranking	AC	No Launch	N20 1 off	WV3 err	MAP fault	ASE OFF	Half-sync	No Knock	AFR warn
EGT shutdown	SYNC fault	No rev lim	Spark cut	N20 2 off	3 step off	TPS Decel	TPS fault	-	No SD	Need Burn	Idle VE	Fan
SD Log	SD ready	No Flat shift	EGT warn	No seq. shift	MAPsample error	No Fuel cut	CL Idle off	Launch Off	Not sync'd	SD Err	Data Logging	Power Cycle

Main Dashboard

Tune opened, 0 bytes updated. File: C:\Users\Public\A\ 2013-08-18\_15.01.18.msq

5:51 PM 8/21/2013